

# Example on how to calculate the build factor

- (A) Lot perimeter squared ÷ (C) Actual lot area
- (B) Actual lot area
- (D) Required lot area

Step 1: Add up the perimeter of the lot (A) and times it by itself (squared).

Step 2: Divide (A) by (B) you will come up with 15.59.

Step 3: Divide (C) by (D) and you will come up with 1.81.

Step 4: Divide 15.59 by 1.81 = 8.61.

8.61 is your build factor number.

